





- 1. Turn on the pump
- 2. Fill water to this hole until the system is full
- 3. Put the cap back after no air bubbles in the system

